# Residential & Landscape Products

DrainMat is the ideal solution to protect entrances from water and debris. DrainMat can be used for residential and commercial use to protect from rain, snow, sand, and everyday debris. Suitable for pedestrian traffic only.

- Reduces transfer of dirt and water into the home or building
- Discreet drainage solution for entrance areas
- Indoor version holds dust and debris and prevents spread around the home

### Suitable applications:

- Residential doorways
- Mud room
- Outdoor showers
- Commercial entrances

# **DrainMat**

## **Base options**



MatFrame Aluminum frame for indoor mat use - small or large



Polymer concrete base with 4" schedule 40 outlet - large



Polymer concrete base with 4" schedule 40 outlet - small




Plastic base with 4" schedule 35 outlet - small only

# **Mat options**

available in small (24" x 16") or large (40" x 20")



Aluminum & rubber mat



Galvanized mesh mat





**DrainMat ACO Self** 

### **Part Table**

	Part No.	Length inches	Width inches	Height inches	Wgt. Ibs.
Bases					
Small (24" x 16")					
Polymer concrete	00398	23.62	15.75	3.15	26.4
Plastic	82400	23.62	15.75	3.15	3.1
Indoor MatFrame	01995	23.62	15.75	1.00	2.0
Large (40" x 20")					
Polymer concrete	00400	39.37	19.69	3.15	49.7
Indoor MatFrame	01997	39.37	19.69	1.00	2.4
Mats					
Small (24" x 16")					
Galv. steel	01207	23.62	15.75	0.79	8.8
Aluminum/rubber	01213	23.62	15.75	0.79	7.7
Stainless	97972	23.62	15.75	0.79	17.6





### **Installation Instructions**

### **Outdoor DrainMat**



Excavate area large enough to fit DrainMat base, add 2" sand and compact well.



Install pipework.



Level base unit. Backfill surround with concrete and finish surface as desired (tile, paver, etc.).



Ensure finished surface is 1/8" higher than the DrainMat to assist water drainage. Fit mat into finished installation.

### **Indoor MatFrame**



Measure area where MatFrame will be placed indoors.



Excavate area large enough to fit DrainMat base.



Install MatFrame, tile floor ensuring surface is 1/8" higher than MatFrame to prevent trip hazard.



Install mat and installation is complete.

### **ACO Polymer Products, Inc.**

### **East Sales Office**

9470 Pinecone Drive Mentor, OH 44060 Tel: (440) 639-7230 Toll free: (877) 553-9961 Fax: (440) 639-7235

### **Southeast Sales Office**

4211 Pleasant Road Ft. Mill, SC 29708 Toll free: (877) 553-9961 Fax: (803) 802-1063

### **West Sales Office**

825 W. Beechcraft St. Casa Grande, AZ 85122 Tel: (520) 421-9988 Toll Free: (877) 553-9961 Fax: (520) 421-9899

# **Electronic Contact**

info@acoself.com www.acoself.com

### Follow us on







