


ACO Infrastructure Maintenance Guide

MonoBloc HD200



1. Confirm that appropriate traffic control is in place to ensure a safe working environment for personnel and equipment.



2. Visually inspect the top of the trench drain for any blockage.



3. Remove the 4 bolts in the HD200 Access Channel with a 15 mm socket.

Lift the grate to gain access to the internal round opening of the trench drain.



4. Insert vacuum hose and 360° pressure jetting hose from vacuum truck into the access channel opening.

5. Move the jetting hose forward through the interior of the trench drain to loosen any debris. Then retract the hose while keeping the jetting system active.

Depending on the amount of debris, this process may be performed repeatedly until the trench drain is clear.

Once complete, remove the hoses.



6. Flush debris from the outside of the channel.



7. Clear the grate frame of debris and bolt the grate to the access channel.



ACO, Inc.

West Sales Office
825 W. Beechcraft Street
Casa Grande, AZ 85122
Tel: (520) 421-9988
Toll-Free: (888) 490-9552
Fax: (520) 421-9899

Northeast Sales Office
9470 Pinecone Drive
Mentor, OH 44060
Tel: (440) 639-7230
Toll-Free: (800) 543-4764
Fax: (440) 639-7235

Southeast Sales Office
4211 Pleasant Road
Fort Mill, SC 29708
Toll-Free: (800) 543-4764
Fax: (803) 802-1063

info@acousa.com
acoswm.com/infrastructure

© April 2022 ACO, Inc.

All reasonable care has been taken in compiling the information in this document. All recommendations and suggestions on the use of ACO products are made without guarantee since the conditions of use are beyond the control of the company. It is the customer's responsibility to ensure that each product is fit for its intended purpose and that the actual conditions of use are suitable. ACO, Inc. reserves the right to change products and specifications without notice. Print #IN700

ACO. we care for water

